

wellcare



Foot Spa

USER MANUAL

Model Number: MM17A300



Contents

- 03 Important Safety Instructions**
- 06 Product Overview**
- 07 Getting Started**
- 08 Operation**
- 09 Other Useful Information**
- 10 Specifications**

Important Safety Instructions

READ CAREFULLY AND KEEP FOR FUTURE REFERENCE

Read this manual thoroughly before first use, even if you are familiar with this type of product. The safety precautions enclosed herein reduce the risk of fire, electric shock and injury when correctly adhered to. Make sure you understand all instructions and warnings. Keep the manual in a safe place for future reference, along with any warranty information, your purchase receipt and the original packaging carton. If you sell or transfer ownership of this product, pass on these instructions to the new owner of the product.

Always follow basic safety precautions and accident prevention measures, including the following:

Usage conditions and restrictions

- This product is intended for private use by adults only. It is not suitable for commercial or trade use. Do not use it for anything other than its intended purpose, and only use it as described in this manual.
- **ALWAYS** unplug this appliance from the electrical outlet immediately after using and before cleaning.
- **DO NOT** reach for product that has fallen into water. Unplug immediately.
- **DO NOT** place or store appliance where it can fall or be pulled into a tub or sink.
- **DO NOT** place in or drop into water or other liquid.

WARNING: TO REDUCE THE RISK OF BURNS, FIRE, ELECTRIC SHOCK OR INJURY TO PERSONS:

- An appliance should never be left unattended when plugged in. Unplug from outlet when not in use and before putting on or taking off parts.
- Close supervisions is necessary when this appliance is used by on, or near children, invalids or disabled persons.
- Use this appliance only for its intended use as described in this manual. Do not use any attachments not provided with the product.
- **NEVER** operate the appliance if it has a damaged cord or plug, if it is not working properly, been dropped or damaged, or dropped into water, contact our After Sales Support.
- **NEVER** drop or insert any object into any opening.
- **NEVER** operate the appliance with the air opening blocked. Keep the air openings free of lint and hair.

Important Safety Instructions (Cont.)

- **DO NOT** operate where aerosol (spray) products are being used or where oxygen is being administered.
- **DO NOT** operate under a blanket or pillow. Excessive heating can occur and cause fire, electric shock or injury to persons.
- **DO NOT** carry this appliance by supply cord or use the cord as a handle.
- **DO NOT** use outdoors.
- **DO NOT** stand on or in appliance. Use only when seated.
- **DO NOT** handle the plug with wet hands
- This product should never be used by any individual suffering from any physical alignment that would limit the capacity to operate the controls, or who have sensory deficiencies.
- **ALWAYS** unplug the unit when filling or moving the unit.
- Ensure that your hands are dry when operating the controls or removing the plug.
- **DO NOT** attempt to plug or unplug the unit while feet are in the water.
- Use the appliance on a sturdy or level surface.
- If water leaks from the appliance, the appliance should no longer be used.
- This appliance has a heated surface. Persons insensitive to heat must be careful when using the appliance.

Health matters

- This product is not intended for medical use.
- Consult your doctor prior to using this product if:
 1. You are pregnant
 2. You have a pacemaker
 3. You have concerns regarding your health
- **NOT** recommended for use by diabetics.
- **NEVER** use the foot spa on any open wounds, discoloured areas, or any area of the body that is swollen, burned or inflamed.
- **NEVER** use the product after surgery or if you are not yet fully recovered.
- If you experience pain in a muscle or joint for an extended period of time, discontinue use and consult your physician.

Important Safety Instructions (Cont.)




ATTENTION: Never turn on power nor operate the product without water in the container.




ATTENTION: This spa is designed for personal and home use only, not for medical or commercial use. Children should not use this spa as a toy.

- **DO NOT** immerse the product in water or other liquids for cleaning.
- **DO NOT** plug or unplug the power source while feet are in the water filled spa.
- **DO NOT** use the spa continuously for more than an hour.
- **DO NOT** use this product while you are sleeping and avoid falling asleep while the product is operating.
- **DO NOT** use the product in a sauna room, on in areas with high humidity or a wet floor.
- **DO NOT** use the product after consuming alcohol, pain killers or sedatives.
- **DO NOT** use the product continuously for more than 60 minutes at a time.
- **DO NOT** use the product while sleeping and avoid falling asleep while the product is operating.
- **NEVER** use the product close to a heater, fireplace, stove or other heating sources.
- **ALWAYS** unplug the power source when you fill water or move the product.
- **ALWAYS** empty out and drain the water after each use.
- It is recommended not to use the spa 30 minutes before or after a meal.



This product is a class II or double insulated electrical appliance. It has been designed in such a way that it does not require connection to electrical earth.

Product Overview



- 1 Acupuncture massage base
- 2 Loofah sponge pad
- 3 Roller massage base & salt/herb/essential oil container (open the base to put in your desired salt, herbs or essential oils).
- 4 Bubble generator x 2
- 5 LED light
- 6 Control knob
- 7 Feet Massagers x 4

Getting Started


Before first use

- Unpack the product and accessories and ensure all parts of the product are undamaged and in good working order. Keep the original packaging carton and materials in a safe place. It will help prevent any damage if the product needs to be transported in the future, and you can use it to store the product when it is not in use. In the event that the packaging is to be disposed of, please recycle all packaging materials where possible.
- Plastic wrapping can be a suffocation hazard for babies and young children, so ensure all packaging materials are out of their reach and disposed of safely.
- Unwind the cord of the power adaptor to its full length and inspect it for damage. Do not use the product if any part is damaged or not working properly. In case of damage, contact our after sales support line for advice.
- Read this manual to familiarise yourself with the product. Pay particular attention to the safety instructions on the previous pages.

Operation

Power on

- Connect the spa to a power source.



1. Mode 3: Bubble mode + LED light mode
2. Mode 0: Turn off
3. Mode 2: LED light mode + keep water warm
4. Mode 1: Bubble mode + keep water warm

Using the device

- Fill the spa with water.
 - Once filled, place the spa on a flat and dry surface.
 - Sit down and place your feet into the container.
 - Turn the control knob to the desired mode.
 - Slide your feet back and forth over the feet massagers.
 - **NOTE:** it is recommended to not use the product for longer than 60 minutes.
 - Turn the control knob to mode 0 to turn the spa off.
-
- After use, tip the water out by the following steps:
 1. Make sure the spa is turned off.
 2. Unplug the power adaptor from the power source.
 3. Tip the spa at an angle, allowing water to pour out.



ATTENTION: Never turn on power nor operate the spa without water in the container.



ATTENTION: Never use the spa while standing up.

Other Useful Information

Troubleshooting

If the foot spa is not working, please check that the power plug is properly connected, then turn the control knob to mode 3. If the LED light still does not turn on and no bubbles are generated, please contact our after sales support.

Cleaning and care

- Before cleaning the product, make sure it is disconnected from power source.
- Clean the water container only with a soft, slightly damp sponge or cloth. Do not use detergents or cleaning agents for cleaning. Dry thoroughly using a dry cloth.
- Do not immerse the product in water.
- If bath salts and/or herbals were used in the session, clean up straight after use.

Storage

- Unplug the product from the power source and allow it to cool down and dry.
- Store the product in the original box to keep dust accumulation to a minimum.
- Do not store the product close to a fireplace or other heating sources.

Service and repair

- The product contains no user-serviceable parts. Do not attempt to take it apart, repair or modify it.
- Do not operate the product if it is damaged or working abnormally. Contact our after sales support centre if a service is required.

Compliance

This appliance has been fully tested and meets all requirements as set out by standards AS/NZS 60335.2.32 for electrical safety.



The RCM Mark (Regulatory Compliance Mark) indicates that the product complies with the relevant guidelines of the ACMA as well as corresponding government requirements for the safety of electrical devices.

Specifications

Power supply	220-240V, 50/60Hz
Max. power consumption	300W
Max. water temperature	60°C
Weight	1.35kg
Dimensions (W x H x D) (mm)	324 x 150 x 380

For Technical and Warranty Support

1300 886 649

tempo.org/support

Distributed by Tempo (Aust) Pty Ltd,
PO Box 132, Frenchs Forest NSW 1640

Notes

wellcare

Warranty returns

Should you for any reason need to return this product for a warranty claim, make sure to include all accessories with the product.

Product does not work?

If you encounter problems with this product, or if it fails to perform to your expectations, make sure to contact our After Sales Support Centre on (AU) 1300 886 649 or (NZ) 0800 836 761 for advice.

Distributed by Tempo (Aust) Pty Ltd ABN 70 106 100 252

PO BOX 132, Frenchs Forest NSW 1640

Customer Helpline:

(AU) 1300 886 649 (NZ) 0800 836 761

Email: tempo.org/support